

ITEM OPPORTUNITY SYNOPSIS

Scouting Number:	2024-16
Name of the item to be scouted:	Barometric Pressure Sensors & Telephone Modems
State item to be used in:	Alaska

Describe the Item:

<p>Please describe the item application/the end use of the item.</p>	<p>The National Oceanic and Atmospheric Administration (NOAA), National Weather Service (NWS), Alaska Region (AR) deploys a network of surface weather stations in remote locations throughout the state transmitting data via the Geostationary Operational Environmental Satellite (GOES) hourly aiding in the collaboration and forecasting process. The NWS AR has been replacing the surface equipment sensors due to obsolescence or failures. The NWS AR requires equipment/devices equivalent to Forest Technology Systems brand barometric pressure sensors, telephone modems, and auxiliary accessories, which are equipped with all required interfacing, components, and features to seamlessly integrate with the existing GOES network.</p>
--	---

Supplier Information:

Type of Supplier Being Sought (select from the list below):

Manufacturer	x
Contract Manufacturer	
Distributor	
Other (Please Specify)	

Reason for Scouting Submission (select from the list below)

2nd Supplier	
Price	
Re-Shore	
Past supplier no longer available	
New Product Startup	
BABA	x
Other (Please Specify)	Buy American Act Waiver

Summary of Technical Specifications and Performance Requirements:

Describe the manufacturing processes (elaborate to provide as much detail as possible)	Electronic Assembly; Various
--	------------------------------

<p>Provide dimensions / size / tolerances / performance specifications of the item</p>	<p>FTS DigiBP: Sensor type: Solid state absolute pressure transducer Interface: SDI-12 v.1.3 Accuracy: 0.2 mbar(hPa) (25°C); 0.3 mbar(hPa) (-40°C to +60°C) Resolution: 0.01 mbar Range: 500 to 1100 mbar(hPa); 14.76 to 32.48 inches of Hg; 50 to 110 KPa; 375 to 825 mm of Hg; 0.49 to 1.08 ATM; 7.25 to 15.95 psia Operating temperature range: -40°C to +60°C Long Term Stability: 0.2% FS per year Measurement time: 6 s Power supply voltage: +12 V DC (nominal range: 9.6 V – 18.6 V) Standby current: 100uA Active current: 12mA Dimensions: see Figure 3-1 Cable length: 0.91 m (3 ft) Weight: 650 g (22.9 oz) TM Ultra: Default connect speed: 14,400 bps Serial port data rate auto baud: enabled Bell 212A operation: 1200 bps Parity: none Auto answer: disabled Command echo: on Results codes: all enabled, except \REL codes Dialing method: touch-tone (T) Busy signal detection: on (ATX4) Full word result codes: non-extended Pulse dial make/break ratio: 39 / 61 - 10 psp Test timer: 0 seconds Text modes: disabled Inactivity timer: 0 min CTS: always active DSR: ignored DCD: ignored RTS to CTS delay: 0.01 seconds DTR: always active; hangs up after transition Long space disconnect: disabled Speaker: enabled; off when receiving carrier Speaker volume: low Local modem will not grant RDL request from remote modem Guard tone: disabled Minimum DTR pulse width: 0.05 s Ring count: 0 Escape code character: ASCII 43 (+) Flash to on hook: 70 ms Auto speed detection: enabled DTE connect speed, connect messages Back space character: ASCII 08 (BS) Carriage return character: ASCII 13 (CR) Line feed character: ASCII 10 (LF) Wait for dial tone before dialing: 2 s Wait for carrier after dialing: 50 s Carrier detect response time: 0.6 s Escape code guard time: 1 s Pause after comma: 2.0 s Lost carrier to hang up delay: 1.4 s DTMF interdigit delay: 0.095 s Auto sync address or address detection: 0 Connection detected at DTE – Highest speed 38,400bps Auto retrain: enabled; 30 seconds attempt MNP error correction: can be negotiated (&Q5) MNP: non-extended service selected MNP error correction block size: 128 characters selected Data compression negotiation: enabled Transmit break length: 0.3 s Breaks: transmitted in sequence with data Serial port flow control: enabled depending on intended use RTS/CTS Note: Upon power-up modem will recall user profile 0 which may override the above factory defaults.</p>
--	--

List required materials needed to make the product, including materials of product components, if applicable	Various and Unknown, except for what is provided within the attached specifications sheets.
--	---

Are there applicable certification requirements?

Yes	
No	x
Please explain:	

Are there any applicable regulations that apply to the production of this item?	
Yes	
No	x
Please explain:	
Are there any other standards / requirements?	
Yes	
No	x
Please explain:	
NAICS CODES:	
NAICS 1	334519 Other Measuring and Controlling Device Manufacturing
NAICS 2	
Additional Comments:	
Additional technical comments:	All equipment/items must be fully compatible (form, fit, and function) with the existing Forest Technology Systems network, without the need for updates or changes to the system or equipment, as all sites are in remote locations throughout Alaska with limited access. Any offered products must be fully interfaceable with the current system without the need for modifications, and function identically to the current equipment to ensure additional costs to the Government for training and maintenance time on site at several remote locations. These measures directly support a successful program for the Alaska Region until a National Training/Equipment standardization program is established.
Volume and Pricing:	
Estimated Potential Business Volume (i.e. #units per day, month, year):	One-time purchase of \$19,370.78 for all products, with estimated shipping of \$665.00
Estimated Target Price/Unit Cost Information:	Target price is to match current total pricing provided by Forest Technology Systems for the following items/quantities: CBL-ULTRA-F6H2, Cable, TM-Ultra to Datalogger, quantity 2 CBL-ULTRA-RJ-11, Cable, TM-Ultra to RJ-11 Telephone Port, quantity 2 TM-ULTRA-KW, Telephone Modem, Keyway Mount, quantity 2 SDI-PT-SS-KEL-USGS, PT, SDI-12, 0-21m (0-70ft), USGS OSW Spec, Stainless Case, quantity 2 SDI-BP-1, Barometric Pressure Sensor, SDI, Keyway, Cable, MC Conn, quantity 3 CBL-H1-BAT-2, Battery Cable, H1 Datalogger, Dual 10A Fuse, quantity 10 CBL-SDI-EXT, Cable, SDI Connection to SDI port, 35 ft, quantity 10
Delivery Requirements:	
When is it needed by? (Immediate, 30 days, 6 months, etc.)	Deliver by 180 days after contract award.
Describe packaging requirements (i.e. individually/group packaging, etc.)	Product must be delivered undamaged with an industry accepted warranty.
Where will this item be shipped?	Anchorage, AK 99502
Additional Comments:	
Is there other information you would like to include?	This is a Simplified Acquisition, which has a shorter lead time to completion than an action over \$250,000.00. It is expected that this requirement will be awarded within the next 30-60 days, and any timely scouting (requested completed within 15 days from submission) would be appreciated to align with Simplified Acquisition requirements for posting and the Buy American Act Waiver process.



EXTREME ENVIRONMENTS. EXTREMELY RELIABLE.



DigiBP (SDI-BP-1)

SDI-12 Digital Barometric Pressure Sensor

User Manual

1.800.548.4264 | www.ftsinc.com



Contact Information

Canadian Headquarters:

1065 Henry Eng Place

Victoria, BC | V9B 6B2 | Canada

www.ftsinc.com



Toll-free: 1.800.548.4264

Local: 250.478.5561



Technical support portal: <http://support.ftsinc.com>



Email: service@ftsinc.com

Contents


CHAPTER 1	GENERAL	1
1.1	DESCRIPTION	1
1.2	INSTALLATION	2
1.3	CONNECTION	2
1.4	OPERATION	3
1.5	CONFIGURATION	3
1.6	CALIBRATION AND MAINTENANCE	3
CHAPTER 2	SDI-12 COMMANDS	4
2.1	NOTATION FOR SDI-12	4
2.2	GENERAL STRUCTURE OF SDI-12 COMMANDS AND RESPONSES	4
2.3	COMMANDS RECOGNIZED BY DIGIBP	5
2.4	GENERAL SDI-12 COMMANDS	6
2.4.1	Address Query	6
2.4.2	Acknowledge Active	6
2.4.3	Change Address	6
2.4.4	Send Identification	7
2.5	SDI-12 Data commands	8
2.5.1	Start Measurement	8
2.5.2	Start Concurrent Measurement	9
2.5.3	Send Data	10
2.6	Extended commands	11
2.6.1	Set/Get Measurement Units Code	12
2.6.2	User Defined Units	13
2.6.3	Set/Get Elevation Offset	13
2.6.4	Calculate And Set Elevation Offset	14
2.6.5	Set/Get Trend Deadband	14
2.6.6	Help Command	15
CHAPTER 3	TECHNICAL SPECIFICATIONS AND COMPLIANCE INFORMATION ...	17
3.1	SPECIFICATIONS	17
3.2	COMPLIANCE INFORMATION	18
3.2.1	Electromagnetic Interference (EMI) – United States FCC Information	18
3.2.2	Electromagnetic Interference (EMI) –CANADA INFORMATION	18
	DOCUMENT REVISION HISTORY	19

Chapter 1 GENERAL

1.1 DESCRIPTION

The FTS DigiBP Barometric Pressure sensor is a simple, compact, rugged SDI-12 device that measures atmospheric pressure and pressure trend. The DigiBP is extremely simple to use: it needs absolutely no configuration in most applications. It is accurate to 0.3 mBar over a temperature range of -40 °C to +60 °C. The DigiBP can be configured to measure barometric pressure in mBar, inches of mercury, kPa, mm of mercury, atmospheres, psia or custom user defined units.

The FTS DigiBP consists of a barometric pressure transducer connected to a microcontroller unit that compensates for ambient temperature and communicates with the data collection platform using the SDI-12 protocol. The data collection platform requests measurements by sending commands to the DigiBP.



1.2 INSTALLATION

For best results the DigiBP should be mounted securely at a fixed elevation. The DigiBP is a very sensitive device and its measurements will be affected by a change in altitude as small as 20 cm. The sensor must be exposed to atmospheric pressure in such a way that measurements are not affected by sealed cabinets, air conditioning systems or wind. A pressure port with a hose barb is provided for situations where the sensor must be placed in a location that is poorly ventilated. A hose with an internal diameter (ID) of 0.17" can be used to connect the sensor via this pressure port to a sheltered outdoor location.


Follow these steps to mount the DigiBP:

1. Mount the sensor on a keyway panel (FTS part number: 993-UCMT-PNL-X) by lining up the shoulder bolts on the back of the enclosure with the key holes on the panel. Once the shoulder bolts are engaged slide the DigiBP down 1 cm to lock it in place.
2. Alternately the DigiBP can be mounted to any flat surface by removing the shoulder bolts and installing appropriate fasteners (i.e. wood screws) through the holes provided.
3. Route the cable safely to the data collection device.
4. If a connector is used, plug the connector into the connector port on the data collection device. If a terminal block is used, refer to section 1.3 for wire colour and function.
5. Connect a hose leading to a static head or other vent to atmosphere to the pressure port hose barb if required.

1.3 CONNECTION

The DigiBP can be supplied with or without a connector. Cable wire colour coding and FTS standard connector¹ pinouts are shown in the table and diagram below:

Wire colour	Pin ¹	Function
Red	A	+12 V DC power supply
White	B	Data
Black	C	Ground



If the DigiBP is supplied without a connector, the user is responsible for connecting the sensor to the data collection platform. Users can attach their own connector, connect the cable via a terminal strip, or wire it directly to device electronics.

¹ Waterproof military-style bayonet connector 851-06JC8-3AP50; FTS part number 520-83AP; compatible with FTS Axiom Dataloggers.

1.4 OPERATION

The FTS DigiBP is an SDI-12 device and is powered by the +12 V DC power supply on the SDI-12 bus. For details on the SDI-12 commands used by the sensor, see Chapter 2.

1.5 CONFIGURATION

The DigiBP is shipped with default address 0 (unless shipped as part of an integrated FTS system). If more than one SDI-12 sensor is on the same bus it may be necessary to change the address. Refer to section **2.4.3 Change Address** for instructions on the command used to set the sensor's address.

1.6 CALIBRATION AND MAINTENANCE

Periodic re-calibration should not be required. Maintenance consists of checking against a reference sensor to ensure accuracy is maintained and verifying that the air inlet is clear of debris.

Please contact FTS technical support (see manual front pages) if the unit ceases to operate properly.

Chapter 2 SDI-12 COMMANDS

2.1 NOTATION FOR SDI-12

SDI-12 commands are strings of characters sent to the SDI-12 sensor by a data logger, data collection platform or other SDI-12 master. The sensor takes action based on the command that was sent (ie. Starting a measurement) and then replies to the command with a string of characters. In this document we use different typefaces to specify the different parts of an SDI-12 command and sensor reply as shown in the following table.

Table 2-1

Item	Meaning	Text representation
Command literal	Part of a command that must be reproduced literally as it appears;	X
Command parameter	Part of a command that must be filled in with an appropriate value.	xxx
Optional parameter	Part of a command that can be omitted if not needed. The brackets [,] are not included in the command.	<i>[xxx]</i>
Floating point number	Number representing a measurement value or command parameter. If a command parameter it will be bolded italic and may be marked as optional.	<i>u.uuuuu</i> , <i>u.uuuuu</i> or <i>[u.uuuuu]</i>
Replies	As above but not bolded	

2.2 GENERAL STRUCTURE OF SDI-12 COMMANDS AND RESPONSES

The general form of an SDI-12 command is as follows:

***a*xxxxx!**

In which ***a*** is the sensor address, ***xxxxx*** is the command code and ***!*** is the command terminator. The addressed sensor will respond with:

***a*yyyyyCRLF**

In which ***a*** is the sensor address, ***yyyyy*** is information the command requested and CRLF are carriage return linefeed characters respectively. The sensor address can be any digit 0-9 or any character a – z or A - Z.

An example of a command/response sequence using an M command for sensor address 3 is shown below:

3M!30042CRLF

2.3 COMMANDS RECOGNIZED BY DIGIBP

The table below provides a quick reference to the commands recognized by the DigiBP. For details on these commands, see the following sections.

Command name	Command code	Notes
Address Query	?!	
Acknowledge Active	a!	
Change Address	aAb!	
Send Identification	a!	
Measurement Commands:		
Pressure, units code	aM[C]!	Optional C requests a CRC code in the data return (D command)
Pressure, units code	aM0[C]!	
Pressure in mB	aM1[C]!	
Pressure, change, trend, units code	aM4[C]!	
Concurrent Measurement Commands:		
Pressure, units code	aC0[C]!	Optional C requests a CRC code in the data return (D command)
Pressure in mB	aC1[C]!	
Pressure, change, trend, units code	aC4[C]!	
Send Data	aDx!	
X commands:		
Set measurement units	aX set mu u!	u is 1 digit code indicating units
Get measurement units	aX get mu!	
Set user defined units scale	aX set us u.uuuu!	<i>u.uuuu</i> is any floating point number
Get user defined units scale	aX get us!	
Set user defined units offset	aX set uo u.uuuu!	<i>u.uuuu</i> is any floating point number
Get user defined units offset	aX get uo!	
Set elevation offset	aX set eo u.uuuu!	<i>u.uuuu</i> is any floating point number
Get elevation offset	aX get eo!	
Calculate and set elevation offset	aX set sce u.uuuu!	<i>u.uuuu</i> is any floating point number
Set trend dead band	aX set tdb u.uuuu!	<i>u.uuuu</i> is any floating point number
Get trend dead band	aX get tdb!	
Help	aX get hlp!	Long reply may not be supported by all data loggers

2.4 GENERAL SDI-12 COMMANDS

General SDI-12 commands are used for housekeeping issues such as device address configuration, device identification and confirmation of device communications. General SDI-12 version 1.3 commands are described in the following sections.

2.4.1 Address Query

This command requests the address of the SDI-12 sensor.

General command/response format: **?!a**CRLF

	String	Note
Cmd	?!	request the (single) device on this bus to report its address
Resp	3	the device is configured for address 3 only one SDI-12 device should be connected to the bus when using this command; problems arise when several devices respond on the same bus

2.4.2 Acknowledge Active

This command queries whether a sensor is present on the SDI-12 bus at the specified address.

General command/response format: **a!**CRLF

	String	Note
Cmd	3!	request the device at address 3 to confirm it is active
Resp	3	a device is present at address 3

2.4.3 Change Address

This command changes a sensor's SDI-12 address.

General command/response format: **aAb!**CRLF

In which: **a** = current address

b = new address

	String	Note
Cmd	3A0!	change the address of the device at SDI-12 address 3 to 0
Resp	0	response confirms change

2.4.4 Send Identification

This command requests detailed identification information from the addressed sensor.

General command/response format: **a!xxxxxxxxxxx\r\n**

	String	Note
Cmd	!0!	
Resp	013FTS-----DigiBPv234567	0 device SDI-12 address 13 compatible with SDI-12 version 1.3 FTS manufacturer's identifier DigiBP sensor model V2 version 2 of sensor firmware 34567 sensor serial number

2.5 SDI-12 DATA COMMANDS

SDI-12 data commands request data from the sensor. Several measurement types are available depending on the user's needs and are described below. Measurements return a pressure value and a units code indicating the value's units and presence of an elevation offset. The following table lists the units codes supported:

Units	Units Code	Units Code w/ Elevation Offset
mB (hPa)	0	10
Inches of Hg	1	11
kPa	2	12
mm of Hg	3	13
Atm	4	14
psia	5	15
User defined	9	19

The **aM4!** Command also returns a trend code that indicates the trend in atmospheric pressure since the last measurement. The following table lists the trend codes supported:

Trend	Trend Code
<i>Falling</i>	-1
<i>Stable</i>	0
<i>Rising</i>	1

2.5.1 Start Measurement

The Start Measurement command are used to trigger a measurement on the addressed sensor and have the following general format:

aM[m][C]!

In which **a** is the address of the sensor, **m** is an optional digit specifying the type of measurement to be made and **C** is an optional character specifying that the measurements should include a CRC for improved error checking.

The sensor will respond immediately to the start measurement command with:

attnCRLF

Where **a** is the sensor's address, **ttt** is the number of seconds until the measurement will be complete and **n** is the number of values that will be returned. The values are obtained after the **ttt** interval has expired using a subsequent Send Data command. A CRC will be included with the values if one was requested using the optional **C** character in the Start Measurement command.

The data logger must not send another command to any SDI-12 sensor on the bus until the measurement is complete or the measurement will be aborted. The measurement is complete when **ttt** seconds have elapsed or the sensor returns a service request consisting of its address back to the data logger.

The measurement types supported by the DigiBP and the values returned by the subsequent D commands are shown in the following table.

Command	Response	Values Returned
aM! or aMC!	a0062	Pressure, units code
aM0! or aM0C!	a062	Pressure , units code
aM1! or aM1C!	a00610	Pressure in mBar to 2 decimals
aM4! or aM4C!	a0064	Pressure to 2 decimals, difference since last measurement, trend code, units code

2.5.2 Start Concurrent Measurement

The Start Concurrent Measurement commands are used to trigger a measurement on the addressed sensor and have the following general format:

aC[m][C]!

In which **a** is the address of the sensor, **m** is an optional digit specifying the type of measurement to be made and **C** is an optional character specifying that the measurements should include a CRC for improved error checking.

The sensor will respond immediately to the start measurement command with:

attnn

In which **a** is the sensor's address, **ttt** is the number of seconds until the measurement will be complete and **nn** is the number of values that will be returned (note the extra digit compared to the

Start Measurement command response). The values are obtained after the **ttt** interval has expired using a subsequent Send Data command and will include a CRC if one was requested.

Unlike the Start Measurement command, the Concurrent Measurement Command does allow the data logger to use the SDI-12 bus to work with other sensors while the measurement is in progress. The measurement is complete when **ttt** seconds have elapsed. The sensor does not send a service request for the Concurrent Measurement command.

The concurrent measurement types supported by the DigiBP and the values returned by the subsequent D commands are shown in the following table.

Command	Response	Values Returned
aC! or aCC!	a00602	Pressure, units code
aC! 0 or aC0C!	a00602	Pressure, units code
aC1! or aC1C!	a00601	Pressure in mBar to 2 decimals
aC4! or aC4C!	a00640	Pressure to 2 decimals, difference since last measurement, trend code, units code

2.5.3 Send Data

This command requests the data generated by the preceding Measurement (**M** or **C**) command.

General command/response format: **aDn!+/-xxx.xxx+/- xxx.xxx +/- xxx.xxxCRLF**

In which: **a** = sensor address
n = digit 0 – 9
 +/- = either '+' or '-' indicating sign of value
 xxx.xxx are floating point values of the measurements.

An **aD0!** command is always the first command sent to retrieve the data. If additional data needs to be read, then an **aD1!** command is sent, then and **aD2!** etc. etc., up to **aD9!**. Since the DigiBP returns only two values (pressure and units code), only an **aD0!** command is ever required with it. The first example below shows a complete measurement command sequence including the Start Measurement command and subsequent Send Data commands.

	String	Note
Cmd	0M!	start a measurement on sensor at address 0
Resp	00062	0 device SDI-12 address 006 measurement delay (until data is ready; seconds) 2 number of data points returned
Cmd	0D0!	request data from previous measurement command
Resp	0+1001.23+0	0 sensor SDI-12 address +1001.23 pressure +0 units code mbar (hPa)

The second example shows a complete measurement sequence with CRC requested in the Start Measurement command.

	String	Note
Cmd	0MC!	start a measurement on sensor at address 0, with CRC in data response
Resp	00062	0 device SDI-12 address 006 measurement delay (until data is ready; seconds) 2 number of data points returned
Cmd	0D0!	request data from previous measurement command
Resp	0+1011.82+0JVk	0 sensor SDI-12 address +1011.82 pressure +0 units code JVk CRC code

2.6 EXTENDED COMMANDS

These commands are used primarily for configuration of the sensor and are manufacturer specific. The general format is:

aXxxxxx...!

In which: **a** = sensor address
X indicates that this is an extended command
xxxxx... is a command specific string of characters.

An extended command for setting configuration parameters has the format:

aX set yyy uuuu!

In which: ***a*** = sensor address
X indicates that this is an extended command
set indicates this is a set command
yyy is the name of the parameter to set
uuuu is the value to which to set it

Similarly an extended command for getting parameters has the format:

aX get yyy!

Where: ***a*** = sensor address
X indicates that this is an extended command
get indicates this is a get command
yyy is the name of the parameter to get

The sensor will reply with the requested parameter.

2.6.1 Set/Get Measurement Units Code

These commands allow the user to set and get the sensor's units of measurement. The default value is 0 (mB).

The set command has the following format:

aX set mu u!

In which ***u*** indicates the measurement units as per the following table:

Units	Units Code
mB (hPa)	0
Inches of Hg	1
kPa	2
mm of Hg	3
Atm	4
psia	5
User defined	9

The get command has the following format and will return the units as outlined in the above table:

aX get mu!

2.6.2 User Defined Units

User defined units are configured by providing a scale and offset for the equation:

$$\text{Measurement} = \text{user scale} * \text{value in mB} + \text{user offset}$$

The default values for user scale and user offset are 1.000 and 0.0000 respectively. The user must set the measurement units to user defined before setting the user scale and user offset values.

2.6.2.1 Set/Get User Defined Units Scale

The command used to set user scale has the following format:

aX set us uuuu.uu!

In which **uuuu.uu** is the value of the new user scale. It can be any valid floating point number.

The get command looks like:

aX get us!

2.6.2.2 Set/Get User Defined Units Offset

The command used to set user offset has the following format:

aX set uo uuuu.uu!

In which **uuuu.uu** is the value of the new user offset. It can be any valid floating point number..

The get command looks like:

aX get uo!

2.6.3 Set/Get Elevation Offset

These commands allow the user to set and get the sensor's elevation offset. The elevation offset is added to the measured value to compensate for the altitude of the sensor. The elevation offset is entered in the current measurement units. Default value is 0.

The command used to set elevation offset has the following format:

aX set eo uuuu.uu!

In which **uuuu.uu** is the value of the new elevation offset which can be any valid floating point number.

The get command looks like:

aX get eo!

2.6.4 Calculate and Set Elevation Offset

This command allows the user to easily set the elevation offset to force the sensor to match a known reference value. The sensor will use the reference value provided in the command and a current measurement to calculate the elevation offset using the equation:

$$\text{elevation offset} = \text{reference value} - \text{measured value}$$

The command has the format:

aX set sce *uuuu.uu*!

In which ***uuuu.uu*** is the reference value expressed in the current measurement units.

For example, if the local pressure is known to be 997.5 mBar then the following command would be sent to the sensor assuming that the sensor address is 7:

7X set sce 997.5!

Subsequent measurement commands will then use the calculated offset so that 997.5 is returned until the local pressure changes.

2.6.5 Set/Get Trend Deadband

These commands allow the user to set and get the deadband used to determine the atmospheric pressure trend. If the change in atmospheric pressure is less than the deadband the trend is "stable" otherwise it is "rising" or "falling" depending on the direction of change. Default value is 0.3 mB.

The set command has the following format:

aX set tdb *uuuu.uu*!

In which ***uuuu.uu*** is the value of the new trend deadband expressed in the current measurement units.

The get command looks like:

aX get tdb!

2.6.6 Help Command

The help command returns a list of all the commands and parameters supported by the sensor. Note that this command may not be supported by all data loggers in transparent mode because of the length of the reply. The command format is:

aX get hlp!

The complete command and response is shown below:

COMMAND/RESPONSE	IN WHICH/COMMENT
aX get hlp	a - address
a aM! - a0062	a - address 006 - seconds until data is ready 2 - 2 fields returned
aD0! - a+1015.23+0	a - address: 0 - units (mB)
aM1! - a0061	a - address 6 - seconds until data is ready 1 - field returned
aD0! - a+1015.23	a - address 1015.23 - data value
aM4! - a0064	a - address 006 - seconds until data is ready 4 - 4 fields returned
aD0! - a+1005.32+0.35+1+0	a - address 1005.32 - current reading 0.35 - difference of last value and current value. 1 - trend is rising 0 - units hPa(mB)

COMMAND/RESPONSE	IN WHICH/COMMENT
aX set mu u!	Set Measurement unit command: u = a numeral from 0 to 5, plus 9 indicating: 0 - mB(hPa) 1 - inches of Hg 2 - kPa 3 - mmHg 4 - Atm 5 - psia 9 - user units
aX set eo x!	Set elevation offset x- levation offset
aX get eo! Elevation Offset = dddd.dd.	Get elevation offset dddd.dd – elevation offset Which would be one of the following: 10 - units in mB plus elevation offset. 11 - units in inches of Hg plus elevation offset. 12 - units in kPa plus elevation offset. 13 - units in mmHg plus elevation offset. 14 - units in Atm plus elevation offset. 15 - units in psia plus elevation offset. 19 - user units.
aX set sce dddd.dd! New offset calculated and saved.	Self calibration of elevation offset Response once the self-calibration is complete
aX set tdb b.bb! aX get tdb b.bb! TDB = b.bb!	Set/Get trend dead band b.bb – value of the trend dead band

Chapter 3 TECHNICAL SPECIFICATIONS AND COMPLIANCE INFORMATION

3.1 SPECIFICATIONS

Sensor type	Solid state absolute pressure transducer
Interface	SDI-12 v.1.3
Accuracy	0.2 mbar(hPa) (25°C) 0.3 mbar(hPa) (-40°C to +60°C)
Resolution	0.01 mbar
Range:	500 to 1100 mbar(hPa) 14.76 to 32.48 inches of Hg 50 to 110 KPa 375 to 825 mm of Hg 0.49 to 1.08 ATM 7.25 to 15.95 psia
Operating temperature range	-40°C to +60°C
Long Term Stability	0.2% FS per year
Measurement time	6 s
Power supply voltage	+12 V DC (nominal range: 9.6 V – 18.6 V)
Standby current	100uA
Active current	12mA
Dimensions	see Figure 3-1
Cable length	0.91 m (3 ft)
Weight	650 g (22.9 oz)




Figure 3-1: DigiBP dimensions (in inches)

3.2 COMPLIANCE INFORMATION

3.2.1 ELECTROMAGNETIC INTERFERENCE (EMI) – UNITED STATES FCC INFORMATION

This equipment has been tested and found to comply with limits for a class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a commercial installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that harmful interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- reorient or relocate the receiving antenna,
- increase the separation between the equipment and receiver,
- connect the equipment into an outlet on a circuit different from that to which the receiver is connected,
- consult the dealer or an experienced radio/TV technician for help.

3.2.2 ELECTROMAGNETIC INTERFERENCE (EMI) – CANADA INFORMATION

This digital apparatus does not exceed the class A limits for radio noise emissions from digital apparatus as set out in the interference causing equipment standard entitled "Digital Apparatus", ICES-003 of the Department of Communications.

Cet appareil numérique respecte les limites de bruits radioélectriques applicables aux appareils numériques de Classe A prescrites dans la norme sur le matériel brouilleur: "Appareils Numériques", NMB-003 édictée par le Ministre des Communications.

DOCUMENT REVISION HISTORY


Revision	By	Date	Description
0	PB	24 Sep 2012	Draft Original. put in current document format.
1.0	PB	15 Oct 2012	Corrections following review
1.1	PB	07 Nov 2012	Firmware version 2 commands added and feedback incorporated
2.0	BC	09 Jun 2017	Put in new format. Cross referenced product name (DigiBP) with model/sales number (SDI-BP-1). Added Long Term Stability to specifications.



TM Ultra

Telephone Modem

User Manual





Contact information

FTS

1065 Henry Eng Place
Victoria, B.C., V9B 6B2
CANADA

www.ftsenvironmental.com

Toll-free	1-800-548-4264
Local	250-478-5561
Technical support	support.ftshydrology.com or support.ftsfireweather.com






Table of Contents


Contact information.....	ii
Table of Figures	4
Chapter 1 Introduction	5
1.1 Description.....	6
1.2 Default status, performance and specs.....	7
1.3 Type of service	7
1.4 Telephone company procedures.....	8
Chapter 2 Installation	9
2.1 Pre-installation setup	10
2.2 Mounting	10
2.3 Grounding	11
2.4 Cables	11
Chapter 3 Troubleshooting	12
Chapter 4 Specifications	15
Appendix A AT commands.....	17
4.2 Overview.....	18
4.3 Basic AT commands:	21
4.4 S-register summary.....	23
4.5 Modem states - dial a number "D"	24
4.6 "AT" command applications	25






Table of Figures

Figure 1-1: TM Ultra modem physical package	6
Figure 3-1: The TM-Ultra front panel.....	13





Chapter 1 Introduction



1.1 Description




Figure 1-1: TM Ultra modem physical package

The TM Ultra is a field hardened telephone modem designed to operate under the harsh conditions found in remote monitoring applications. It supports standard modulation, error control and data compression protocols so that it can connect with any standard desktop PC modem without need for special initialization strings for the PC modem.

Connection to the telephone line and to the data terminal equipment (usually a datalogger) is via waterproof military connectors on the modem's front panel. The cast aluminum case is O-ring sealed and contains a desiccant pack to protect the internal electronics from corrosion due to moisture. The case is designed to be mounted on a wall or equipment enclosure back panel.

Three-stage surge suppression is provided on all connector pins to protect against lightning and electrostatic discharge. A heavy ground stud is also provide for connecting a site ground system to the modem. The telephone connection is also protected against power cross faults which occur when power lines accidentally come in contact with the telephone lines. This condition is commonly caused when telephone company cables are damaged during wind storms.

The TM Ultra is designed as a low power device. It operates from a 6 - 20 VDC supply and uses 260 micro amps in standby mode. When in standby mode the modem will answer incoming calls and respond to serial communications from the data terminal equipment. It will return to standby mode approximately 25 seconds after a call is completed or serial data stops. Standby mode can be disabled by asserting the DTR line.

1.2 Factory default status, performance and specs

Default connect speed	14,400 bps	DTE connect speed, connect messages	
Serial port data rate auto baud	enabled	Back space character	ASCII 08 (BS)
Bell 212A operation	1200 bps	Carriage return character	ASCII 13 (CR)
Parity	none	Line feed character	ASCII 10 (LF)
Auto answer	disabled	Wait for dial tone before dialing	2 s
Command echo	on	Wait for carrier after dialing	50 s
Result codes	all enabled, except \REL codes	Carrier detect response time	0.6 s
Dialing method	touch-tone (T)	Escape code guard time	1 s
Busy signal detection .	on (ATX4)	Pause after comma	2.0 s
Full word result codes	non-extended	Lost carrier to hang up delay	1.4 s
Pulse dial make/break ratio	39/61 - 10 psp	DTMF interdigit delay	0.095 s
Test timer	0 seconds	Auto sync address or address detection	0
Test modes	disabled	Connection detected at DTE - Highest speed 38,400bps.	
Inactivity timer	0 min	Auto retrain	enabled; 30 seconds attempt
CTS	always active	MNP error correction	can be negotiated (&Q5)
DSR	ignored	MNP	non-extended service selected
DCD	ignored	MNP error correction block size	128 characters selected
RTS to CTS delay	0.01 seconds	Data compression negotiation	enabled
DTR	always active; hangs up after transition	Transmit break length	0.3 s
Long space disconnect	disabled	Breaks	transmitted in sequence with data
Speaker	enabled; off when receiving carrier	Serial port flow control	enabled depending on intended use RTS/CTS
Speaker volume	low		
Local modem will not grant RDL request from remote modem.			
Guard tone	disabled		
Minimum DTR pulse width	0.05 s		
Ring count	0		
Escape code character	ASCII 43 (+)		
Flash to on hook	70 ms		
Auto speed detection .	enabled		

NOTE: Upon power-up modem will recall user profile 0 which may override the above Factory Defaults.

1.3 Type of service

The TM-Ultra is designed to be used on standard device telephone lines. It connects to the telephone line by means of a standard jack called the USOC RJ-11C (or USOC FJ45S). Connection to telephone company

provided coin service (central office implemented systems) is prohibited. Connection to party lines service is subject to state tariffs.

1.4 Telephone company procedures

The goal of the telephone company is to provide you with the best service it can. In order to do this, it may occasionally be necessary for them to make changes in their equipment, operations or procedures. If these changes might affect your service or the operation of your equipment, the telephone company will give you notice, in writing, to allow you to make any changes necessary to maintain uninterrupted service. In certain circumstances, it may be necessary for the telephone company to request information from you concerning the equipment which you have connected to your telephone line. Upon request of the telephone company, provide the FCC registration number and the ringer equivalence number (REN); both of these items are listed on the equipment label on the back of the modem. The sum of all of the RENs on your telephone lines should be less than five in order to assure proper service from the telephone company. In some cases, a sum of five may not be useable on a given line.

1.4.1 If problems arise


If any of your telephone equipment is not operating properly, you should immediately remove it from your telephone line, as it may cause harm to the telephone network. If the telephone company notes a problem, they may temporarily discontinue service.

When practical, they will notify you in advance of this disconnection. If advance notice is not feasible, you will be notified as soon as possible. When you are notified, you will be given the opportunity to correct the problem and informed of your right to file a complaint with the FCC.

Contact your telephone company if you have any questions about your phone line. In the event repairs are ever needed on the TM-Ultra, they should be performed by FTS Forest Technology Systems or an authorized representative of FTS Forest Technology Systems. For information contact: FTS Forest Technology Systems at any of the telephone numbers or addresses listed in the beginning of this user's manual.



Chapter 2 Installation



2.1 Pre-installation setup

Each TM Ultra unit is pre-configured at the factory to work with the datalogger it is intended for use with. Normally, your TM Ultra should work “out of the box” and you should not have to do any pre-installation setup. Only in special cases will you need the information in this section.

Pre-installation setup may be needed on TM Ultra units that are being moved to another application environment or are otherwise misconfigured for their currently intended use. FTS is happy to perform pre-installation set-up in these cases if you wish (please contact us).

Certain customers prefer to do pre-installation setup for themselves. If you are one of these customers, you will need the custom TM Ultra setup cable sent to you from FTS and the information in the table below.

Pre-installation setup consists of sending the TM Ultra certain command strings from a PC running a terminal emulation program such as Windows Terminal or Hyperterminal. Command strings must be sent at 9600 BPS, no parity, 8 data bits, 1 stop bit.

The command strings you must send depend on the datalogger (and in some cases, the datalogger connector) with which the TM Ultra unit will be used. The question comes down to whether the datalogger uses flow control when communicating with the TM Ultra.

Consult the table below for the command strings required for your datalogger:

Dataloggers	Flow control	Command strings
FWS-12S FWS-12S, Telemetry Port, RMX	Enabled	AT&F&C1&D0[cr] AT+MS=V32B,1,2400,14400,2400,14400[cr] AT\N5-K1[cr] ATS10=50S0=1[cr] AT\V1E0[cr] AT&W0&W1[cr]
FWS-11 FWS-12S, Display Port Axiom F6, H2, or H1, FTS Port	Disabled	AT&F&C1&D0[cr] AT+MS=V32B,1,2400,14400,2400,14400[cr] AT\N5-K1[cr] ATS10=50S0=1[cr] AT&K0\V1E0[cr] AT&W0&W1[cr]

2.2 Mounting

The TM-Ultra is designed to be mounted on a 1/8-inch thick metal enclosure panel that has been punched with keyholes to accept the shoulder screws on the back of the modem case. Simply align the shoulder screws with the keyholes and slide it down until it stops. Alternately, the modem can be mounted on any reasonably flat wall surface using the mounting kit available from FTS.

To install using the mounting kit first remove the shoulder screws from the back of the case align the mounting plate with the shoulder screw holes and re-install and tighten the shoulder screws. Next hold the modem in the desired location on the wall surface and mark the position of the mounting slots on the wall. Finally drill holes at the marked positions and mount the modem using screws or bolts appropriate for the mounting surface type.

2.3 Grounding

In order for the modem's lightning protection system to operate properly the modem must be well grounded. The grounding stud on the lower left of the front panel is provided for this purpose.

Connect the grounding stud to the site ground with a short length of 12 AWG or larger ground wire. The ground wire should be routed away from other circuits with as few bends as possible. The site ground should consist of driven ground rods, Ufer ground system or buried ground radial conductors or combinations of all three. The lower the impedance of the ground connection, the better chance the modem has of surviving surges caused by lightning.

2.4 Cables

2.4.1 Telephone and telemetry connections

The TM-Ultra is always supplied with two cables. First is a cable for connecting to the telephone system. It has a two pin military style connector on one end and a common RJ-11 connector for plugging into a telephone jack on the other. The second is a telemetry cable that connects the TM-Ultra to the datalogger and in some cases to an external power supply.

First connect the two pin MS connector on the end of the telephone cable to the black connector marked **TELEPHONE** on the TM-Ultra front panel. Connect the other end of this cable to a RJ-11 telephone wall jack that is in a dry location out of the weather. Next connect the blue coded 10 pin MS connector to the blue connector marked **TELEMETRY** on the TM-Ultra front panel. Connect the green coded MS connector on the other end of this cable to the green connector marked **TELEMETRY** on the datalogger.

2.4.2 Power for FWS-11, FWS-12, and FWS-12S dataloggers


The power supply will be either an AC adapter or a pair of ring lugs for connecting to the station's battery pack depending, on the option ordered. Connect the power supply by plugging in the AC adapter or connecting the ring lugs to the battery terminals.

2.4.3 Power for Axiom dataloggers (F6, H1, H2)

Axiom dataloggers provide power to the TM Ultra through the telemetry port. There is no need for a separate power connection.



Chapter 3 Troubleshooting



Five status lights have been included on the front panel to help in troubleshooting. These lights are normally off when the modem is not active, to save power. They should only come on when a connection is in progress or if either the datalogger or a remote modem is attempting to establish a connection. The following is a brief description of each light's function.




Figure 3-1: The TM-Ultra front panel.


ACTIVE	This light is on when power is applied and the modem is not in sleep mode. The modem will not be in sleep mode immediately after power is applied, if a ring signal has been detected within the last 25 seconds, if the logger has sent data to the modem in the last 25 seconds, if the DTR line is being held on or if a connection is in progress.
RINGING	This light will flicker briefly when a ring signal is detected on the telephone line. That is, when the modem is being called. The ACTIVE light should come on almost immediately after this light flickers as the modem comes out of sleep mode.
ON LINE	This light will come on and stay on when a connection with a remote modem is established. If the RINGING light flickers followed by the ACTIVE light coming on but the ON LINE light does not come on, then the modem is unable to establish a connection. This may be due to the modem not being in auto answer mode, the remote modem not being in a compatible mode, or a poor telephone line.
TRANSMITTING	This light will come on when the datalogger sends data to the modem. If the modem is not active (ACTIVE light off) when this light flickers the modem should immediately become active in order to process the data from the logger.

RECEIVING

This light will come on when the modem sends data to the datalogger. If a remote connection is established and this light flickers periodically before the call is dropped, it is probably due to the modem not being able to wake up the datalogger. This could be caused by a damaged cable to the datalogger, a low power supply voltage to the datalogger, or a damaged datalogger.




Chapter 4 Specifications



Power Supply Voltage:	6-20 VDC
Power Consumption (@ 12 VDC)	133 mA when off hook 126 mA when on hook 0.26 mA quiescent
Electrical protection	Three stage transient suppression on all input and output termination's for lightning and electrostatic discharge protection. Self healing power cross protection on Telephone line connection: 110VAC Tip to Ring, 110VAC Tip or ring to ground. Self healing reverse polarity power supply protection.
Operating temperature range:	-40 to +85 C
Approvals/Certifications	FCC part 68 approved
Interoperability	Connects with commercially available modems without special initialization commands.
Connect time including dialing:	15 - 20 s
Connection speeds	300, 1200, 2400, 4800, 9600 or 14400 bps
Modulation	V.34bis, V.34 V.DC, V.32bis, V.32, V.22bis, V.22A/B, V.23, V.21, Bell 212A and Bell 103
Error Correction	V.42 LAMP, MNP 2-4 and MNP 10 enhanced throughput cellular
Data Compression	V.42bis and MNP 5
Modem Control Protocol	AT command structure with extensions
Lines	DTE interface supports txd, rxd, rts, cts, dtr and dsr lines.
Adaptability	Automatic baud rate adaptability



Chapter 5 AT commands



5.1 Overview

5.1.1 AT commands

An “AT command” is an ASCII string that can be sent to the modem to set its configuration or instruct it to perform certain actions. Each such command must begin with the characters AT.

This chapter outlines the key information on AT commands as it applies to the TM Ultra. For full details, see the FTS external document numbered “701-Cermetek Modem AT-Commands-S-Register-Rev-H4-1.”

5.1.2 Definitions

A command line is a string of characters sent from a controller (e.g., a computer) to the modem while the modem is in a command state. A command line has a prefix, a body, and a terminator.

Each command line (with the exception of the A/ command) must begin with the character sequence AT and must be terminated by a carriage return (denoted [CR]).

Commands entered in upper case or lower case are accepted, but both the A and T must be of the same case, i.e., “AT” = ASCII 065, 084 or “at” = ASCII 097, 116.

The body is a string of commands restricted to printable ASCII characters (032-126). Space characters (ASCII 032) and control characters other than [CR] (ASCII 013) and [BS] (ASCII 010) in the command string are ignored.

The default terminator is the ASCII [CR] character. Characters that precede the AT prefix are ignored.

Example

```
ATE0A[CR]
```

~~E0A~~ is the body of the command.

5.1.3 Entering and editing AT commands

When entering commands to the modem, the backspace character - control-H (ASCII 8) - can be used to edit mistakes.

AT and A/ may not be edited however.

5.1.4 AT command set

See Page 14 for a summary list of AT commands.

5.1.5 Status messages and result codes

The modem responds with a status message after each command is executed and result codes after a modem connection is made or attempted.

Status messages may either be terse (one or two decimal digits, followed by a carriage return) or may be verbose (a carriage return and line feed, followed by a message in English, followed by a carriage return and line feed). See Table 5-1 below.

All AT commands, other than dialing commands, will be responded to with either an OK (0) if the command is valid or accepted, or with an ERROR (4) if the command is not recognized.

All other messages fall in the category of call progress status or result codes. Examples:

- RING (2) - while the remote modem is being called, each ring will be signaled to the DTE.
- NO ANSWER (8) will indicate a failed connection attempt.
- When the modem connects, result codes will be signaled to the DTE.

Result codes, non-extended, from 9 - 35 are listed in Table 5-1 below. Result codes extended beyond 35 can be optionally selected with the ATXn command and status register S95. It is recommended that the non-extended result codes be used in all cases. The (default) connect messages 9 - 17 indicate a connection at a given DTE speed, not Carrier (Line) speed. Hence a TM-Ultra will connect at maximum speed of 19,200 (15). Certain subsets of status and result codes can be specified by the ATXn command.

The basic status code subsets are enabled with the Xn command, n = 0, 1, 2, 3, 4. Status codes can be in message form or result code form. See the detailed description of the ATXn command for result code options.

Extensions to the basic set can be specified by Register S95, which covers result codes 40 - 81.

Options with S95 are:

- Enable compression result codes 66, 67, 69 Enable error protocol result codes 76, 77, 80, 81
- Enable carrier result codes 40 - 58
- Enable DCE rather than DTE speed result codes 59 - 64
- To obtain a detailed status report of a given modem communication, use the AT\V1 command. When this command has been executed at setup the modem will return a connect message on line consisting of:
`<DTE speed> <modulation> <error protocol> <line speed of connection>`

Table 5-1: Status messages and result codes

	Terse	Verbose	Result Codes (ATXn)				
			0	1	2	3	4
0	OK		X	X	X	X	X
1	CONNECT		X	X	X	X	X
2	RING		X	X	X	X	X
3	NO CARRIER		X	X	X	X	X
4	ERROR		X	X	X	X	X
5	CONNECT 1200		1	X	X	X	X
6	NO DIAL TONE		3	3	X	X	X
7	BUSY		3	3	3	X	X
8	NO ANSWER		X	X	X	X	X
9	CONNECT 0600		1	X	X	X	X
10	CONNECT 2400		1	X	X	X	X
11	CONNECT 4800		1	X	X	X	X
12	CONNECT 9600		1	X	X	X	X

Terse	Verbose	Result Codes (ATXn)				
		0	1	2	3	4
13	CONNECT 7200	1	X	X	X	X
14	CONNECT 12000	1	X	X	X	X
15	CONNECT 14400	1	X	X	X	X
16	CONNECT 19200	1	X	X	X	X
17	CONNECT 38400	1	X	X	X	X
18	CONNECT 57600	1	X	X	X	X
19	CONNECT 115200	1	X	X	X	X
22	CONNECT 75TX/1200RX	1	X	X	X	X
23	CONNECT 1200TX/75RX	1	X	X	X	X
24	DELAYED	4	4	4	4	X
25	MESSAGE-WAITING					
32	BLACKLISTED	4	4	4	4	X
33	FAX	X	X	X	X	X
35	DATA	X	X	X	X	X
40	+MRR:300	X	X	X	X	X
42	+MRR: 600	X	X	X	X	X
44	+MRR: 1200/75	X	X	X	X	X
45	+MRR: 75/1200	X	X	X	X	X
46	+MRR: 1200	X	X	X	X	X
47	+MRR: 2400	X	X	X	X	X
48	+MRR: 4800	X	X	X	X	X
49	+MRR: 7200	X	X	X	X	X
50	+MRR: 9600	X	X	X	X	X
51	+MRR: 12000	X	X	X	X	X
52	+MRR: 14400	X	X	X	X	X
66	+DR: ALT	X	X	X	X	X
67	+DR: V.42B	X	X	X	X	X
68	+DR: V44	X	X	X	X	X
69	+DR: NONE	X	X	X	X	X
70	+ER: NONE	X	X	X	X	X
77	+ER: LAPM	X	X	X	X	X
80	+ER: ALT	X	X	X	X	X
81	+ER: ALT-CELLULAR	X	X	X	X	X
83	LINE IN USE	X	X	X	X	X
85	OFF-HOOK INTRUSION	X	X	X	X	X
86	LINE REVERSAL DETECTED	X	X	X	X	X
87	NO LINE	X	X	X	X	X
91	CONNECT 31200	X	X	X	X	X
130	+ILRR	X	X	X	X	X

134	+MCR: B103	X	X	X	X	X
135	+MCR: B212	X	X	X	X	X
136	+MCR: V21	X	X	X	X	X
137	+MCR: V22	X	X	X	X	X
138	+MCR: V22B	X	X	X	X	X
139	+MCR: V23	X	X	X	X	X
139	+MCR: V23C	X	X	X	X	X
140	+MCR: V32	X	X	X	X	X
141	+MCR: V32B	X	X	X	X	X
210	+MRR: 25333	X	X	X	X	X
211	+MRR: 26667	X	X	X	X	X
212	+MRR: 25333	X	X	X	X	X
213	+MRR: 22666	X	X	X	X	X
214	DIGITAL LINE DETECTED	X	X	X	X	X

Note: X in a column indicates that the message will be generated when that particular value of 'n' (shown at the top of the column) has been selected by the use of ATXn. A numeral indicates which less explicit message (verbose or terse form) will be output for that X option.

5.2 Selected AT commands

This table includes only the most common AT commands and those used in the pre-installation setup (section 2.1). For full details, see the FTS external document numbered “701-Cermetek Modem AT-Commands-S-Register-Rev-H4-1.”

Command	Function
A/	Re-execute command
A	Go off-hook and attempt to answer a call
B0	Select V.22 connection at 1200bps
B1	Select Bell 212A connection at 1200bps
C1	Return OK message
Dn	Dial modifier
P	Pulse Dial
T	Touch Tone Dial
W	Wait for Dial Tone
;	Return to Idle State
@	Wait for Quiet Answer Command
!	Flash Hook
,	Pause
0-9/ABCD	Dial Digits/Characters
&	Wait for credit card dial tone
^	Toggles calling tone
L	Redial last number

	*	Star digit - tone dialing
	S=n	Dial the number and store in directory. N=0 to 3
E0		Turn off command echo
E1		Turn on command echo
F0		Select auto-detect mode (equivalent to N1)
F1		Select V.21 or Bell 103
F2		Reserved
F3		Select V.23 line modulation
F4		Select V.22 or Bell 212A 1200bps line speed
F5		Select V.22bis line modulation
F6		Select V.32bis or V.32 4800 line modulation
F7		Select V.32bis 7200 line modulation
F8		Select V.32bis or V.32 9600 line modulation
F9		Select V.32bis 12000 line modulation
F10		Select V.32bis 14400 line modulation
H0		Initiate a hang-up sequence
H1		If on-hook, go off-hook and enter command mode
&C0		Force RLSD active regardless of the carrier state
&C1		Allow RLSD to follow the carrier state
&D0		Interpret DTR On to OFF transition per &Qn: &Q0, &Q5, &Q6. The modem ignores DTR
&D1		Interpret DTR On to OFF transition per &Qn: &Q0, &Q5, &Q6. Asynchronous escape
&D2		Interpret DTR On to OFF transition per &Qn: &Q0, &Q5, &Q6. The modem hangs up
&D3		Interpret DTR On to OFF transition per &Qn: &Q0, &Q5, &Q6. The modem performs soft reset
&F0		Restore factory configuration 0
&F1		Restore factory configuration 1
&K0		Disable DTE/DCE flow control
&K3		Enable RTS/CTS DTE/DCE flow control
&K4		Enable XON/XOFF DTE/DCE flow control
&K5		Enable transparent XON/XOFF flow control
&K6		Enable both RTS/CTS and XON/XOFF flow control
\N0		Select normal speed buffered mode
\N1		Select direct mode
\N2		Select reliable link mode
\N3		Select auto reliable mode
\N4		Force LAPM mode
\N5		Force MNP mode
\V0		Connect messages are controlled by the command settings X, W, and S95
\V1		Connect messages are displayed in the single line format
+MS		Select modulation

&W0	Store the active profile in NVRAM profile 0
&W1	Store the active profile in NVRAM profile 1
-K0	Disable MNP 10 extended services
-K1	Enable MNP 10 extended services
-K2	Enable MNP 10 extended services detection only

5.3 S-register summary

Register	Function	Range	Units	Saved	Default
S0	Rings to Auto-Answer	0-255	rings	*	0
S1	Ring Counter	0-255	rings		0
S2	Escape Character	0-255	ASCII	*	43
S3	Carriage Return Character	0-127	ASCII		13
S4	Line Feed Character	0-127	ASCII		10
S5	Backspace Character	0-255	ASCII		8
S6	Wait Time for Dial Tone	2-255	s		2
S7	Wait Time for Carrier	1-255	s		50
S8	Pause Time for Dial Delay Modifier	0-255	s	*	2
S9	Carrier Detect Response Time	1-255	0.1s	*	6
S10	Carrier Loss Disconnect Time	1-255	0.1s	*	14
S11	DTMF Tone Duration	50-255	0.001s	*	95
S12	Escape Prompt Delay	0-255	0.02s	*	50
S13	Reserved	-	-		-
S14	General Bit Mapped Options Status	-	-	*	138 (8Ah)
S15	Reserved	-	-		-
S16	Test Mode Bit Mapped Options Status (&T)	-	-		0
S17	Reserved	-	-		-
S18	Test Timer	0-255	s	*	0
S21	V.24/General Bit Mapped Options Status	-	-	*	52 (34h)
S22	Speaker/Results Bit Mapped Options Status	-	-	*	117 (75h)
S23	General Bit Mapped Options Status	-	-	*	62 (3Dh)
S24	Reserved	-	-		-
S25	Delay to DTR Off	0-255	s or .01s		5
S26	RTS-to-CTS Delay	0-255	0.01s		1
S27	General Bit Mapped Options Status	-	-	*	73 (49h)
S28	General Bit Mapped Options Status	-	-	*	0
S30	Disconnect Inactivity Timer	0-255	10s		0
S31	General Bit Mapped Options Status	-	-	*	194 (C2h)
S32	XON Character	0-255	ASCII		17 (11h)
S33	XOFF Character	0-255	ASCII		19 (13h)
S34-S35	Reserved	-	-		-
S36	LAPM Failure Control	-	-	*	7

S37	Line Connection Speed	-	-	*	0
S38	Delay before Forced Hang-up	0-255	s		20
S39	Flow Control Bit Mapped Options Status	-	-	*	3
S40	General Bit Mapped Options Status	-	-	*	104 (68h)
S41	General Bit Mapped Options Status	-	-	*	195 (C3h)
S42-S45	Reserved	-	-		-
S46	Data Compression Control	-	-	*	138
S48	V.42 Negotiation Control	-	-	*	7
S82	LAPM Break Control	-	-		128 (40h)
S86	Call Failure Reason Code	0-255	-		-
S95	Result Code Messages Control	-	-	*	0

Register value may be stored in one of two user profiles with the &W command.

5.4 Modem states - dial a number "D"

The modem can be in either a command mode or a data mode. When the modem is idle it is in the command state. The Dial command takes the form `Dn`, where `n` is a string of data characters. In the simplest form, `n` will be only the digits of the phone number to be dialed.

When a call is in progress the modem is in the data mode state. The modem does not recognize commands when in the data mode. For the modem to recognize commands, the computer must send an "escape sequence" to the modem that forces it out of the data mode and into the command mode.

The escape sequence consists of a "guard time" (a period where no characters are sent to the modem), followed by 3 escape characters, followed by a "guard time" again. At power up, the guard time is set to 1 second minimum and the escape character is set as "+". These two parameters can be modified via registers S2 and S12 (see section 5.3).

The modem will stay off-hook with its carrier on after the escape sequence is received. It returns an OK status message when it is ready to accept commands. You may re-renter the data mode by issuing the ONLINE command `ATO[CR]`.

Example: Dial number.

Enter: `AT D5554567`

In response to this command, the modem dials the telephone number "555-4567" and then waits for carrier from a distant modem. If no carrier is detected within a given time (the default time is 30 seconds), the modem automatically releases the line and sends a NO CARRIER result code. If carrier is detected, the modem gives a CONNECT result code and goes on-line, permitting communication with the distant modem.

The Dial Command may also be issued without a telephone number. `ATD` causes the modem to pick up the telephone line without dialing a number.

5.5 AT command applications

Pause

When placing a call from an office with a telephone connected to a PBX, it may be necessary to dial an access code (usually the digit 9) to get an outside line. Inserting a comma in the telephone number commands the modem to pause for a specific length of time. Since a modem communicates data serially, and most host products handle data in a parallel format, a UART is needed to make parallel-to-serial and serial-to-parallel translations. The default pause time is 2 seconds.

Example: Dial 9, pause, dial number.

Enter: ATDT9 , T1234567

Multiple commas may be used for a greater delay time.

Touch Tone And Pulse Dialing "T" and "P"

The modem can use DTMF (touch-tones) "T", or dial pulses "P" when dialing a telephone number. If the dial command does not specify which type to use, the modem defaults to the type last specified. The power-on default value is T.

Example: Pulse dial 9, pause, touch-tone dial number.

Enter: ATDP9 , T1234567

Redial Last Number "A/"

Use A/, the repeat command, to redial the last telephone number dialed when a busy signal is received.

Return to Command State";"

The modem can be forced to reenter the command state after dialing (without hanging up) by ending the dial command with a semicolon. This is useful when using the modem as an auto dialer.

Example: Touch-tone dial 9, pause, dial number, return for
command.

Enter: AT DT9 , 1234567 ;

Result: OK

Automatic Answering

The S0 register controls the number of rings that must occur before the modem answers a call. The register may range in value from 0-255.

S0=0 DO NOT ANSWER TELEPHONE (the modem will not auto-answer)

S0=1-254 ANSWER ON RING 1 TO RING 254

S0=255 ANSWER ON RING 255